

Shanghai Normal University

Tutorial (T04) - Compaction

Daniel Barreto

May 2025

1. The natural water content of a soil is 10%. Assuming 2100 g of wet soil is used for laboratory compaction tests, calculate how much water is to be added to other 2100 g samples to bring their water contents up to 13, 17, 20 and 24%.
2. The following results were obtained from a standard compaction test on a soil. The value of G_s is 2.67. Plot the dry density-water content curve, and

Mass (g)	2010	2092	2114	2100	2055
Water content (%)	12.8	14.5	15.6	16.8	19.2

give the optimum water content and maximum dry density. The volume of the mould is 1000 cm³.

3. For the data given below ($G_s = 2.64$):
 - a) Plot the compaction curves.
 - b) Establish the maximum dry density and optimum water content for each test.
 - c) Plot the zero air voids line. Also plot the 70, 80 and 90% saturation curves.
 - d) Plot the line of optimums.

Heavy compaction		Standard compaction	
Dry density	w (%)	Dry density	w (%)
1.873	9.3	1.691	9.3
1.91	12.8	1.715	11.8
1.803	15.5	1.755	14.3
1.699	18.7	1.747	17.6
1.641	21.1	1.685	20.8
		1.619	23